



Part 13 is a shim that is to be mounted or glued to the leg assembly. Glue parts in the order 14, 15, 16, 17, 16, 17, 18 with 14 on the bottom. Reverse the order for the right horse shoe.

The leg provides keyholes so the horse shoe can be installed and removed easily. Use the corresponding holes in the horse shoe to screw in wood type screws. You will have to experiment with the depth of the screws for the best fit of the horse shoe onto the leg assembly.