

A&A Leg Tutorial

_____ 29

_____ 30

The sheet styrene pieces are laid out in the approximate locations. Most of the parts are just glued to the leg to cover the grooves formed when stacking the layers. This option can be used or the builder can use putty if they want. A glue that is compatible with PVC and Styrene should be used such as an epoxy.

Ankle parts No 20 and No 21 have to be assembled onto the legs. This is one option or a resin front can be installed.

Glue the parts together following the lettering system. Glue No 20 to No 19 first. Once the glue has dried you can glue on No 21.

There are 5 sets of keyholes

1. Leg Hub
2. Booster Cover
3. Resin Ankle cover
4. Ankle Cylinder
5. Ankle Cylinder Holder

