

Here is the finished legs with all the extras included.

Part 39 and 40 are the horse shoe buttons. Stack two No 39s and one No 40. Due to material limitations the button is not compleat but will give you something to put in the horse show for now. Later on the builder can upgrade to something a bit more accurate if desired.

Part 37 and 38 are the ankle details. As above the limitations of the material does not allow up to provide a compleat part. To get it compleat some filing and sanding will be needed. Again the builder can leav it as is, modify it to be compleat or replace it.

Parts 31-33 are the cylinder holder. To make this compleat stack them so that Part 33 is closest to the ankle and Part 32 is furthest. You will have to curve the inside to surface to accept the cylinder. Mounting holes are provided on both parts.

Parts 34 are sandwiched together to make the cylinder wedge. To make it compleat the side will have to be bevelled in.

Parts 35 and 36 are wedges. They are to be used if the builder wants to. They are designed to go under the ankle to act as a stop. If your droid is in 3 legged mode Part 36 is placed under the ankle to prevent the ankle from tilting further then desired. Part 35 is to place under the ankle for 2 legged mode.

